



OWNER'S MANUAL



GP25 LOADER **PARTS and INSTRUCTIONS**

1242 ARIZONA AVE.
LARCHWOOD, IA 51241
1-800-570-8205



DANGER



TO PREVENT POSSIBLE ROLLOVER, OBSERVE THE FOLLOWING SAFETY PRECAUTIONS

- ◆ Carry loads as low as possible
- ◆ Drive tractor slowly when turning, operating on hills or inclines, or traversing uneven ground
- ◆ Raise load to full height *only* when tractor is on even ground and front wheels are straight ahead

TO PREVENT POSSIBLE PERSONAL INJURY, OBSERVE THE FOLLOWING SAFETY PRECAUTIONS

- ◆ Never walk or work under a raised loader that is not firmly supported
- ◆ Always relieve the hydraulic system to zero pressure before performing repairs on any component of the loader's hydraulic system

TABLE OF CONTENTS

- Composite Bearing Information
- Mounting Loader on Tractor
- Dismounting Loader
- Quick-attach Instructions
- Parts Schematics
- Cylinder Packing Detail
- Loader Specifications
- Warranty

SERIAL No. of Loader Purchased _____

Date Purchased _____

COMPOSITE BEARING INFORMATION




FIGURE A. Your GP/GL-Series loader is equipped with composite, greaseless bearings at all (12) pivot points. These high-quality bearings should not be confused with plastic bushings, sintered bushings, or metal-backed bearings. Composite bearings are made from an ultra-strong fiberglass composite that has twice the compressive yield strength of plain carbon steel. Their greaseless feature is due to a Teflon-impregnated liner that is interwoven to the bearing's inside diameter. The bearings are designed to last the life of the loader and the pins that rotate in the bearings should exhibit practically no wear.




FIGURE B. Even though the composite bearings on your GP/GL-Series loader have excellent resistance to dirt particles, the (4) pivot points on the bucket have an added feature. The two lower bucket cylinder pivots and the two mainframe-to-bucket pivots are equipped with pin seals on each end of the bearing housing. It is these four pivot points that are usually down in the dirt and grime, but with a GP/GL-Series loader, you won't have to worry about pin failures again!




FIGURE C. Should any of your bearings have to be removed, this photo shows the tool that is available to remove and install the bearings properly. They are available for purchase, you just need to tell your dealer or Miller Loaders the model of loader you have. If you'd prefer to make your own, here are a few things to remember:

- The nose should be 1/4" longer than the bearing
- A 1/4" bevel on the end of the nose
- The shoulder must be just slightly smaller than the outside diameter of the bearing
- The diameter of the nose should be about 0.005 less than the inside diameter of the bearing

MOUNTING LOADER




FIG. 1




FIG. 2



FIG. 3



FIG. 4A




FIG. 4B

Support shaft

Upright mast




FIG. 4C

V-Block

Tapered Guide Block




FIG. 5



FIG. 6

Stand Legs




FIG. 7

Stand Legs Stored

STEP 1 For a new loader installation, the mountings must be installed on the tractor first. Refer to the typical mounting kit shown in Figure 1. A detailed schematic of your specific kit is available—just call 1-800-570-8205 if the schematic was not included with your new loader.

STEP 2 The loader should have been dismantled (or assembled) on flat, level ground (see Figure 2).

STEP 3 Approach the loader as shown in Figure 3 and connect the hydraulics.





STEP 4 Once the hydraulics are functional, begin to slowly tip the bucket forward from its flat position, see Figure 4A. This will bring the upright masts of the loader towards the support shafts on the mountings (Fig. 4B). Figure 4C shows the mast completely seated on the support shaft. Once the mast is resting on the support shaft, the V-block will also be aligned with the tapered guide block. The lift cylinders can be used to rotate the upright mast and firmly seat the V-block against the guide block.

STEP 5 Using a 1-1/2" socket or end wrench, install and tighten the 1" retaining bolt that secures the V-block to the guide block. See Figure 5.

STEP 6 Raise the bucket off the ground so that the stand legs are hanging free. See Figure 6.

STEP 7 Return the stand legs to their stored position. See Figure 7.

DISMOUNTING LOADER



STEP 1 DRIVE THE TRACTOR ONTO FLAT CONCRETE and place the loader in the position shown in Fig 1.

STEP 2 Remove the stand legs from their stored position and place them in their dismount position. Slide the inner tubes down to the extended position and secure them with the 3/4" pins. See Fig. 2.

STEP 3 Gently lower the loader until the stand legs touch the ground. Please note that the stand legs are not designed to withstand all of the down-force that can be generated with the lift cylinders, they are designed to support the weight of the loader only. Rotate the bucket so that the cutting edge and stand legs are all resting on the ground. See Fig. 3.

STEP 4,5 Using a 1-1/2" socket or end wrench, remove the 1" retaining bolt that secures the V-block to the guide block. See Figures 4,5.

STEP 6 Using the bucket cylinders, slowly flatten the bucket. This will start to lift the upright mast out of the pillar mount, see Figure 6A. When the bucket is completely flat on the ground, the upright mast will be high enough to back away from the loader. See Figure 6B

STEP 7 Disconnect the hydraulic supply to the loader and slowly back away from the loader. See Figure 7.

QUICK-ATTACH INSTRUCTIONS




FIGURE 1.




FIGURE 2.





FIGURE 3.

UNCOUPLING

1. Raise sliding latches as shown in Figure 1.
2. Rotate QT pins out of the lower notches, raise, and then rotate them into the upper notches of the sliding latches as shown in Figure 2.
3. Slide the sliding latches down as shown in Figure 3. This secures the QT pins in the “up” position so they do not interfere when hooking up to the next attachment.

COUPLING

1. Approach and hook onto the attachment with QT pins secured in the “up” position as shown in Figure 3.
2. When the QT frame is flat against the attachment, raise the sliding latches as shown in Figure 2.
3. Rotate QT pins out of the upper notches, lower, and then rotate them into the lower notches on the sliding latches as shown in Figure 1. **NOTE:** If the QT pins do not easily slide thru the lug on the attachment, do not force them. Simply rotate the attachment back and forth slowly with the bucket cylinders of the loader and the QT pins should fall into place. Periodically grease the QT pins and sliding latches.
4. Secure the QT pins in the “down” position by sliding the latches down.



ITEM NO.	PART NUMBER	DESCRIPTION	Default/QTY.
2	PN-600AC16	PIN, CHROME 2" x 6" WITH RETAINER	2
3	PN-700AC16	PIN, CHROME 2" x 7" WITH RETAINER	2
4	PN-650AC12	PIN, CHROME 1-1/2 x 6-1/2 WITH RETAINER	2
5	PN-725AC12	PIN, CHROME 1-1/2 x 7-1/4 WITH RETAINER	2
6	PN-11B12	REAR BUCKET CYLINDER PIN	2
7	PN-4750-J12	LIFT CYLINDER PIN, 1-1/2 CHROME	2
8	HW-LS-16-A	LOCKWASHER, 1-IN., MED ZN	2
9	HW-LS-08-A	LOCKWASHER, 1/2, MED ZN	10
10	HW-NS-16-B	NUT, 1-14 UNF, GR5, NZ	2
11	HW-NS-16-E	NUT, 1-14 UNF GR8 TL, ZN	2
12	HW-NS-10-A	NUT, 5/8-11 UNC GR8, ZN	1
13	HW-NS-08-A	NUT, 1/2-13 UNC, ZN	10
16	LV01-04	SLIDE ROD ASSY, LEVEL INDICATOR	1
17	HW-BS-08-0200-A	BOLT, 1/2-13 UNC, GR5 ZN, 2" LONG	8
18	HW-BS-10-0100-A	BOLT, 5/8-11 UNC, GR5 ZN, 1" LONG	1
19	HW-BS-08-0150-A	BOLT, 1/2-13 UNC, GR5 ZN, 1-1/2" LONG	1
20	HW-WS-08-A	WASHER, 1/2" FLAT, ZN	3
21	MF25	MAINFRAME, GL25/GP25	1
22	QT25	QUICK ATTACH FRAME	1
29	LV01-01	SLIDE TUBE ASSY, LEVEL INDICATOR	1
30	LV01-03	LEVEL INDICATOR ROD, 5/8 x 48	1
31	UP25-AR	UPRIGHT LEG, RIGHT	1
32	CY-062-L	CYLINDER, GP25 LIFT, LH	1
33	CY-062-R	CYLINDER, GP25 LIFT, RH	1
35	UP25-AL	UPRIGHT LEG, LEFT	1
36	CY-063	CYLINDER, BUCKET, GL/GP25	2

better built

MILLER

farm loaders

SCHEMATIC

GP25 LOADER

GENERAL PART LIST

DWG. NO. **GP25**


REV. **A**


WEIGHT: 1766.443

DATE 1/14/2005

SHEET 1 OF 1


ITEM NO.	PART NUMBER	DESCRIPTION	with bearings/QTY.
20	BR-2500K-3750	COMPOSITE BEARING, 2.00 BORE, 3.75 LONG	2
21	PS-2000-45	Pin Seal (MRW), 2.0 ID x 2.5 OD x 5/16 Thick	8
22	BR-2000K-1500	COMPOSITE BEARING, 1.50 BORE, 1.50 LONG	2
23	BR-2500K-3125	COMPOSITE BEARING, 2.00 BORE, 3.125 LONG	2





MILLER SCHEMATIC
 farm loaders

MAINFRAME, GL25/GP25
 BEARING & SEAL DETAIL

DWG. NO. MF25	REV. A
WEIGHT: 928.756	DATE 1/27/2005
SHEET 1 OF 1	



SLIDING LATCH DETAIL



ITEM NO.	PART NUMBER	DESCRIPTION	Pin Up Latch Up/QTY.
1	QT02-01L	SLIDING LATCH ASSY, QT, LH	1
2	QT02-01R	SLIDING LATCH ASSY, QT, RH	1
3	QT02-14	RETAINING PIN ASSEMBLY, QT	2
4	QT25-W	WELDED QT FRAME, GL/GP25	1

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
4	HW-NS-06-A	NUT, 3/8-16 UNC, CL, ZN	4
5	HW-SP-01	SPRING, QT HANDLE	4
6	HW-WS-06-A	WASHER, 3/8, FLAT, ZN	4



QUICK ATTACH FRAME
GL25/GP25

DWG. NO. QT25


REV.
A


WEIGHT: 241.551

DATE 1/16/2005

SHEET 1 OF 1

ITEM NO.	PART NUMBER	DESCRIPTION	with piping/QTY.
1	HP25P-LU	LIFT FEEDLINE, UPPER	1
2	HP25P-LL	LIFT FEEDLINE, LOWER	1
3	HP25P-BL	BUCKET TILT FEEDLINE, LOWER	1
4	HP25P-BU	BUCKET TILT FEEDLINE, UPPER	1
5	HP25-HLL	LIFT CYLINDER HOSE, LONG (28.5")	2
6	HP30-HLS	LIFT CYLINDER HOSE, SHORT (24")	2
7	HP30-HBL	BUCKET CYLINDER HOSE, LONG (45.5")	2
8	HP30-HBS	BUCKET CYLINDER HOSE, SHORT (41")	2
9	HW-BS-05-0125-A	BOLT, 5/16-18 UNC, GR5 ZN, 1-1/4" LONG	7
10	HW-LS-05-A	LOCKWASHER, 5/16, ZN	7
11	PC06X2	PIPE CLAMP	7






MILLER SCHEMATIC
 farm loaders

GL25/GP25
 HOSES & PIPING

DWG. NO. HP25	REV. A
WEIGHT: 20.992	DATE 1/16/2005
SHEET 1 OF 1	

ITEM NO.	PART NUMBER	DESCRIPTION	Aux kit/QTY.
1	HP25P-GL	AUXILLARY FEEDLINE, LOWER	1
2	HP25P-GU	AUXILLARY FEEDLINE, UPPER	1
3	PC06X2	PIPE CLAMP	2
4	HW-LS-05-A	LOCKWASHER, 5/16, ZN	2
5	HW-BS-05-0125-A	BOLT, 5/16-18 UNC, GR5 ZN, 1-1/4" LONG	2
6	SF-2706-LN-10-08	BULKHEAD CONNECTOR, -10 JIC to 1/2 NPT	2
7	HOSE	SPECIFY LENGTH REQUIRED	2
8	HA-TP-4050-3	TIP, FEMALE 3/8 NPT (PIONEER 4050-3)	1
9	HA-TP-4010-3	TIP, MALE 3/8 NPT (PIONEER 4010-3)	1
10	SF-5405-06-08	EXPANDING PIPE ADAPTER, 3/8 to 1/2 NPT	2






MILLER SCHEMATIC
 farm loaders

GL/GP25 LOADER
 AUX. LINE KIT

DWG. NO. AU25	REV. A
WEIGHT: 8.494	DATE 1/16/2005
SHEET 1 OF 1	


ITEM NO.	PART NUMBER	DESCRIPTION	Stand Legs/QTY.
1	SL25-TL	TOP TUBE ASSY, LEFT	1
2	SL25-BL	BOTTOM TUBE ASSY, STAND LEG (LH)	1
3	SL25-HL	STAND LEG HANDLE, LEFT	1
4	SL25-TR	TOP TUBE ASSY, RIGHT	1
5	SL25-BR	BOTTOM TUBE ASSY, STAND LEG (RH)	1
6	PIN1-006	CLEVIS PIN, 3/4 X 3 1/2 ZNC	2
7	PIN1-017	HAIRPIN COTTER, 2-11/16 LONG	6
8	HW-NS-16-E	NUT, 1-14 UNF GR8 TL, ZN	2
9	SL25-HR	STAND LEG HANDLE, RIGHT	1





MILLER SCHEMATIC
 farm loaders

GL25/GP25 LOADER
STAND LEG PART LIST

DWG. NO. SL25H	REV. A
WEIGHT: 76.917	DATE 1/16/2005
SHEET 1 OF 1	



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	CY-059T	TUBE ASSEMBLY, GP/GL25-30 BUCKET	1
2	CY-063D	ROD ASSY, GL/GP25 BUCKET	1
3	CP-GL-3017-S	GLAND, 3017, SHORT-TAIL	1
4	CP-PS-3017-U	PISTON, 3017 U-CUP	1
5	HW-NS-16-A	NUT, 1-14 UNF, TOP LOCK, PLAIN	1
6	CP-KT-3017-U	P-KIT, 3.000 X 1.750 UC	1
7	BR-2000K-3125	COMPOSITE BEARING, 1.50 BORE, 3.125 LONG	1
8	BR-2000K-3750	COMPOSITE BEARING, 1.50 BORE, 3.75 LONG	1
9	PS-1500-45	Pin Seal (MRW), 1.50 ID x 2.0 OD x 5/16 Thick	4



NOTES:
 1. BEARINGS AND SEALS ARE SOLD SEPARATELY.
 2. PACKING KIT SHOWN IN PART LIST, BUT NOT SHOWN IN DRAWING.

CY-063
 CYLINDER, GL/GP25 BUCKET


ALL DIMENSIONS IN INCHES

BORE ϕ	3.000
ROD ϕ	1.750
STROKE	20-5/8"
PORT STYLE	-08 JIC
WEIGHT:	50.500 LBS.


SCHEMATIC
 CYLINDER, GL/GP25 BUCKET

DWG. NO. CY-063

DATE 1/27/2005 SHEET 1 OF 1



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	CP-GL-3220-L	GLAND, 3220 LONG-TAIL	1
2	CP-PS-3220-U	PISTON, 3220 U-CUP	1
3	HW-NS-16-A	NUT, 1-14 UNF, TOP LOCK, PLAIN	1
4	CP-KT-3220-U	P-KIT, 3.250 X 2.000 UC	1
5	CY-062-LT	TUBE ASSEMBLY, GP25 LIFT, LH	1
6	CY-062D	ROD ASSEMBLY, GP25 LIFT	1
7	BR-2000K-3125	COMPOSITE BEARING, 1.50 BORE, 3.125 LONG	1
8	PS-1500-45	Pin Seal (MRW), 1.50 ID x 2.0 OD x 5/16 Thick	2




CY-062-L
 LIFT CYLINDER, GP25, LH

NOTES:
 1. BEARING AND SEALS ARE SOLD SEPARATELY.
 2. PACKING KIT SHOWN IN PART LIST, BUT NOT SHOWN IN DRAWING.

ALL DIMENSIONS IN INCHES

BORE ϕ	3.250
ROD ϕ	2.000
STROKE	28-1/2"
PORT STYLE	-08 JIC
WEIGHT:	71.283 LBS.



MILLER
farm loaders


SCHEMATIC

LIFT CYLINDER, GP25, LH


DWG. NO. **CY-062-L**

DATE 1/27/2005

SHEET 1 OF 1



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	CP-GL-3220-L	GLAND, 3220 LONG-TAIL	1
2	CP-PS-3220-U	PISTON, 3220 U-CUP	1
3	HW-NS-16-A	NUT, 1-14 UNF, TOP LOCK, PLAIN	1
4	CP-KT-3220-U	P-KIT, 3.250 X 2.000 UC	1
5	CY-062D	ROD ASSEMBLY, GP25 LIFT	1
6	CY-062-RT	TUBE ASSEMBLY, GP25 LIFT, RH	1
7	BR-2000K-3125	COMPOSITE BEARING, 1.50 BORE, 3.125 LONG	1
8	PS-1500-45	Pin Seal (MRW), 1.50 ID x 2.0 OD x 5/16 Thick	2



CY-062-R
 LIFT CYLINDER, GP25, RH

NOTES:
 1. BEARING AND SEALS ARE SOLD SEPARATELY.
 2. PACKING KIT SHOWN IN PART LIST, BUT NOT SHOWN IN DRAWING.

ALL DIMENSIONS IN INCHES

BORE ϕ	3.250
ROD ϕ	2.000
STROKE	28-1/2"
PORT STYLE	-08 JIC
WEIGHT:	71.283 LBS.

SCHEMATIC

LIFT CYLINDER, GP25, RH


DWG. NO. **CY-062-R**

DATE 1/27/2005 SHEET 1 OF 1


SEAL, U-CUP, LARGE

O-RING, LARGE

B/U WASHER



O-RING, SMALL



ROD WIPER

SEAL, U-CUP, SMALL


SNAP RING

PISTON


GLAND

FRONT OF CYLINDER



		<p>SCHEMATIC</p> <p>PACKING CONFIGURATION, U-CUP</p>	
<p>DWG. NO. CP-KT-U</p>		<p>REV. A</p>	
<p>WEIGHT:</p>		<p>DATE 1/13/2005</p>	
<p>SHEET 1</p>		<p>OF 1</p>	

GP25 SPECIFICATIONS



SPECIFICATIONS AND PERFORMANCE NUMBERS ARE FOR REFERENCE ONLY

LIFTING CAPACITY:

Breakaway Lift	: 5900 lbs.
Full Height Lift	: 4900 lbs.

With load 800mm (31.5") ahead of bucket pivot
And 2850 psi pressure at lift cylinders

WEIGHTS:

Loader (less bucket and mounts)	: 1790 lbs.
7 FT Bucket	: 720 lbs.
Mounting Kit (Typical)	: 690 lbs.
Total:	: 3200 lbs.



WARRANTY

Dec 2004

ALL PRODUCTS MANUFACTURED BY MILLER LOADERS, INCORPORATED (**MLI**) EXCEPT THE CHROME-PLATED PIVOT PINS USED ON GREASELESS LOADERS, ARE GUARENTEED TO THE ORIGINAL PURCHASER FOR A PERIOD OF ONE YEAR FROM THE DAY OF PURCHASE AGAINST ANY DEFECTS IN MATERIALS AND WORKMANSHIP OF FARM LOADERS AND ATTACHMENTS THAT ARE USED IN NORMAL FARM OPERATIONS. THE CHROME-PLATED PIVOT PINS USED ON GREASELESS LOADERS ARE GUARENTEED TO THE ORIGINAL PURCHASER FOR A PERIOD OF FIVE YEARS FROM THE DAY OF PURCHASE AGAINST ANY DEFECTS IN MATERIALS AND WORKMANSHIP OR AGAINST WEAR THROUGH OF THE CHROME FINISH COVERING AT LEAST ONE-QUARTER OF THE PIN SURFACE.

ALL GREASELESS COMPOSITE BEARINGS SOLD BUT NOT MANUFACTURED BY **MLI** ARE GUARENTEED TO THE ORIGINAL PURCHASER FOR A PERIOD OF FIVE YEARS FROM THE DAY OF PURCHASE AGAINST BREAKAGE OR LOSS OF THEIR SELF-LUBRICATING PROPERTY.

THE FIVE YEAR WARRANTY FOR THE CHROME-PLATED PIVOT PINS AND GREASELESS COMPOSITE BEARINGS IS LIMITED TO THE PARTS ONLY. **MLI** IS NOT RESPONSIBLE FOR ANY LABOR NECESSARY FOR THE INSPECTION, REMOVAL, OR REPLACEMENT OF SAID PIVOT PINS AND/OR COMPOSITE BEARINGS.

ALL PARTS SOLD BUT NOT MANUFACTURED BY **MLI** THAT INCLUDE BUT ARE NOT LIMITED TO ZINC-PLATED PINS, HOSES, VALVES, QUICK COUPLERS, PUMPS, TANKS, ETC. ARE COVERED ONLY TO THE EXTENT OF THE MANUFACTURE'S WARRANTY ON THESE ITEMS. **MLI** DOES NOT WARRANTY THESE ITEMS EXPRESSLY OR IMPLIEDLY.

DEFACEMENT OF ANY PART BY WELDING OR OTHERWISE ALTERING, OR EXCESSIVE WEAR ON PINS CAUSED BY LACK OF LUBRICATION, NULLIFIES THE WARRANTY ON THE **MLI** PRODUCT.

MLI ASSUMES NO RESPONSIBILITY AS TO THE PERFORMANCE OR FAILURE OF A TRACTOR'S HYDRAULIC SYSTEM.

THE HYDRAULIC COMPONENTS OF THE **MLI** PRODUCTS ARE GUARENTEED UP TO A PRESSURE OF 3000 POUNDS PER SQUARE INCH AT A MAXIMUM FLOW RATE OF 30 GALLONS PER MINUTE.

MLI ASSUMES NO RESPONSIBILITY FOR THE FAILURE OF THE PURCHASER TO SECURE THE LOADER TO THE TRACTOR PROPER, WHICH INCLUDES PROPER BOLT TIGHTENING AND SECURING OF ALL CONNECTION POINTS.

ALL ITEMS MANUFACTURED BY **MLI** REQUIRING WARRANTY CONSIDERATION MUST BE RETURNED TO **MLI** OR A DESIGNATED REPRESENTATIVE BY THE ORIGINAL PURCHASER. ANY ITEM SO RETURNED BY COMMON CARRIER MUST BE PREPAID FREIGHT.

THE WARRANTIES PROVIDED BY **MLI** AS REFERRED TO ABOVE SHALL BE THE SOLE AND EXCLUSIVE WARRANTIES. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF **MLI** WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY.

IN NO EVENT SHALL THE WARRANTIES OF **MLI** REQUIRE MORE FROM **MLI** THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY, **MLI** SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

MILLER LOADERS INC, 1242 ARIZONA AVE, LARCHWOOD, IA 51241

PHONE: 1-800-570-8205
Or (712) 477-2795

FAX: (712) 477-2500